Aircraft wi-fi mobile control and figure and function operation method.

Download the application

* If your mobile phone is apple series, please directly connected to the App Store download search Exploration UFO software and installation; Also can direct scanning on the right side or color box on the qr code to download and install.



TOS

* If your mobile phone for android series, foreign users please connect to the Google Play Store search download the Exploration UFO software and installation; Also can direct scanning on the right side or color box on the qr code to download and install.



Google

* Domestic users, please download in the android market search Exploration UFO software and installation; Also can direct scanning on the right side or color box on the qr code to download and install.



Android







Note:

On the android platform to intercept WeChat part function WeChat to any download links, may cause the qr code click on the download is not successful, this is WeChat development team specialized design, prevent competitors from a download link by WeChat download page. Scan the qr code is recommended to use UC browser tool

Wi-fi connection method

- 1. Please refer to instruction manual open the aircraft power supply open;
- 2, into the mobile phone Settings WiFi function, open the WiFi switch and select the WiFi signal from the aircraft (WiFiUFO - * * * * *), directly connected after a successful exit interface Settings;



Application methods:

- 1, found in the cell phone installed Exploration UFO software icon, click open the home page into the interfaceSuch as (figure 1), click START to go into the real-time transmission images such as (figure 2), then click on the control Switch OFF into the manipulation of the interface, such as (figure 3), the aircraft lights, normally on the aircraft For manipulation.
- Click operating instructions manual describes the interface to enter Such as (as shown in figure 4, figure 5).

